

Seer-F450C	17CH Mode1	14CH Mode2	DMX Value	Funciton
<b>Dimmer</b>	<b>1</b>	<b>1</b>	<b>0---255</b>	<b>Darkness-----&gt;Bright</b>
<b>Dimmer FINE</b>	<b>2</b>		<b>0---255</b>	
<b>Strobe</b>	<b>3</b>	<b>2</b>	<b>0---3</b> <b>4---103</b> <b>104---107</b> <b>108---207</b> <b>208---212</b> <b>213---225</b> <b>226---238</b> <b>239---251</b> <b>252---255</b>	<b>Closed</b> <b>Slow Strobe---&gt;Fast Strobe</b> <b>Open</b> <b>Slow Pulsation---&gt;Fast Pulsation</b> <b>Open</b> <b>Random Slow Strobe</b> <b>Random Medium Strobe</b> <b>Random Fast Strobe</b> <b>Open</b>
<b>Color</b>	<b>4</b>	<b>3</b>	<b>0---4</b> <b>5---12</b> <b>13---21</b> <b>22---29</b> <b>30---38</b> <b>39---46</b> <b>47---55</b> <b>56---63</b> <b>64---72</b> <b>73---81</b> <b>82---89</b> <b>90---98</b> <b>99---106</b> <b>107---115</b> <b>116---123</b> <b>124---189</b> <b>190---255</b>	<b>WHITE</b> <b>RED</b> <b>ORANGE</b> <b>AQUAMARINE</b> <b>GREEN</b> <b>LIGHT GREEN</b> <b>LAVENDER</b> <b>PINK</b> <b>YELLOW</b> <b>MAGENTA</b> <b>CYAN</b> <b>CTO 260</b> <b>CTO 190</b> <b>CTB 8000</b> <b>BLUE</b> <b>CW</b> <b>SlowRotation-----&gt;FastRotation</b> <b>CCW           FastRotation-----&gt;Slow</b> <b>Rotation</b>

<b>Fixed Gobo</b>	<b>5</b>	<b>4</b>	<b>0---3</b> <b>4---7</b> <b>8---11</b> <b>12---15</b> <b>16---19</b> <b>20---23</b> <b>24---27</b> <b>28---31</b> <b>32---35</b> <b>36---39</b> <b>40---43</b> <b>44---47</b> <b>48---51</b> <b>52--- 55</b> <b>56---59</b> <b>60---63</b> <b>64---67</b> <b>68---71</b> <b>72---113</b> <b>114---117</b> <b>118---159</b> <b>160---166</b> <b>167---172</b> <b>173---179</b> <b>180---185</b> <b>186--- 191</b> <b>192---198</b> <b>199---204</b> <b>205---211</b> <b>212---217</b> <b>218---223</b> <b>224---230</b> <b>231---236</b> <b>237---243</b> <b>244---249</b> <b>250---255</b>	<b>WHITE</b> <b>GOBO 1</b> <b>GOBO 2</b> <b>GOBO 3</b> <b>GOBO 4</b> <b>GOBO 5</b> <b>GOBO 6</b> <b>GOBO 7</b> <b>GOBO 8</b> <b>GOBO 9</b> <b>GOBO 10</b> <b>GOBO 11</b> <b>GOBO 12</b> <b>GOBO 13</b> <b>GOBO 14</b> <b>GOBO 15</b> <b>GOBO 16</b> <b>GOBO 17</b> <b>CW</b> <b>FastRotation-----&gt;SlowRotation</b> <b>WHITE</b> <b>CCW</b> <b>SlowRotation-----&gt;FastRotation</b> <b>GOBO2 Shake Slow----&gt;Fast</b> <b>GOBO3 Shake Slow----&gt;Fast</b> <b>GOBO4 Shake Slow----&gt;Fast</b> <b>GOBO 5 Shake Slow----&gt;Fast</b> <b>GOBO6 Shake Slow----&gt;Fast</b> <b>GOBO7 Shake Slow----&gt;Fast</b> <b>GOBO8 Shake Slow----&gt;Fast</b> <b>GOBO9 Shake Slow----&gt;Fast</b> <b>GOBO10 Shake Slow----&gt;Fast</b> <b>GOBO11 Shake Slow----&gt;Fast</b> <b>GOBO12 Shake Slow----&gt;Fast</b> <b>GOBO13 Shake Slow----&gt;Fast</b> <b>GOBO14 Shake Slow----&gt;Fast</b> <b>GOBO15 Shake Slow----&gt;Fast</b> <b>GOBO16 Shake Slow----&gt;Fast</b>
<b>Prism</b>	<b>6</b>	<b>5</b>	<b>0---127</b> <b>128---255</b>	<b>EXCLUDED</b> <b>INSERTION</b>
<b>Prism2</b>	<b>7</b>	<b>6</b>	<b>0---127</b> <b>128---255</b>	<b>EXCLUDED</b> <b>INSERTION (STOP)</b>
<b>Prism2Rotation</b>	<b>8</b>	<b>7</b>	<b>0---255</b>	<b>SlowRotation-----&gt;FastRotation</b>

<b>FOCUS</b>	<b>9</b>	<b>8</b>	<b>0---255</b>	
<b>FOUCS FINE</b>	<b>10</b>		<b>0---255</b>	
<b>PAN(X)</b>	<b>11</b>	<b>9</b>	<b>0---255</b>	
<b>PAN(X) FINE</b>	<b>12</b>	<b>10</b>	<b>0---255</b>	
<b>TILTE(Y)</b>	<b>13</b>	<b>11</b>	<b>0---255</b>	
<b>TILTE(Y) FINE</b>	<b>14</b>	<b>12</b>	<b>0---255</b>	
<b>XY Rotation</b>	<b>15</b>		<b>0---128</b> <b>129---170</b> <b>171---211</b> <b>212---255</b>	<b>Undefined</b> <b>Undefined</b> <b>Undefined</b> <b>Undefined</b>
<b>Lamp Control</b>	<b>16</b>	<b>13</b>	<b>0---32</b> <b>33---64</b> <b>65---96</b> <b>97---128</b> <b>129---160</b> <b>161---193</b> <b>194---225</b> <b>226---255</b>	<b>Undefined</b> <b>LAMP OFF(&gt;4s)</b> <b>Undefined</b> <b>LAMP ON(&gt;4s)</b> <b>Undefined</b> <b>HALF POWER</b> <b>Undefined</b> <b>FULL POWER</b>
<b>Control</b>	<b>17</b>	<b>14</b>	<b>0---127</b> <b>128---255</b>	<b>Undefined</b> <b>Reset ALL( &gt;4s)</b>