

Ares-S5A	24CH Mode1	21CH Mode2	DMX Value	Funciton
Dimmer	1	1	0---255	Darkness----->Bright
Dimmer FINE	2		0---255	
Strobe	3	2	0---3	Closed
			4---103	Slow Strobe--->Fast Strobe
			104---107	Open
			108---207	Slow Pulsation--->Fast Pulsation
			208---212	Open
			213---225	Random Slow Strobe
			226---238	Random Medium Strobe
			239---251	Random Fast Strobe
			252---255	Open
Color1	4	3	0--5	White
			6---12	Color1+WHITE
			13---19	Color1
			20---26	Color1+Color2
			27---33	Color2
			34---40	Color2+Color3
			41---47	Color3
			48---54	Color3+Color4
			55---61	Color4
			62---68	Color4+Color5
			69---76	Color5
			77---83	Color5+Color6
			84---90	Color6
			91---97	Color6+Color7
			98---104	Color7
			105---111	Color7+Color8
			112---118	Color8
			119---127	Color8+Color9
			128---134	Color9
			135---141	Color9+Color10
142---148	Color10			
149---155	Color10+WHITE			
156---205	CW Rotation Slow--->Fast			
206---255	CCW Rotation Fast--->Sloww			
Cyan	5	4		
Magenta	6	5		
Yellow	7	6		
Color Macro	8			

Fixed Gobo	9	7	0---3 4---7 8---11 12---15 16---19 20---23 24---27 28---31 32---35 36---39 40---76 77---84 85---121 122---137 138---153 154---169 170---185 186---201 202---217 218---223 224---239 240---255	WHITE GOBO 1 GOBO 2 GOBO 3 GOBO 4 GOBO 5 GOBO 6 GOBO 7 GOBO 8 GOBO 9 CW SlowRotation----->FastRotation WHITE CCW SlowRotation-----> FastRotation GOBO 1 Shake Slow---->Fast GOBO 2 Shake Slow---->Fast GOBO 3 Shake Slow---->Fast GOBO 4 Shake Slow---->Fast GOBO 5 Shake Slow---->Fast GOBO 6 Shake Slow---->Fast GOBO 7 Shake Slow---->Fast GOBO 8 Shake Slow---->Fast GOBO 9 Shake Slow---->Fast
Gobo1 Select	10	8	0---2 3---5 6---10 11---16 17--- 22 23---28 29---34 35---40 41---52 53---70 71---88 89---106 107--124 125---142 143---160 161---178 179---196 197---226 218---255	WHITE GOBO1 GOBO2 GOBO3 GOBO4 GOBO5 GOBO6 GOBO7 GOBO8 GOBO1 Shake Slow---->Fast GOBO2 Shake Slow---->Fast GOBO3 Shake Slow---->Fast GOBO4 Shake Slow---->Fast GOBO5 Shake Slow---->Fast GOBO6 Shake Slow---->Fast GOBO7 Shake Slow---->Fast GOBO8 Shake Slow---->Fast CW SlowRotation----->FastRotation CCW FastRotation-----> SlowRotation
GOBO1 index Rotation	11	9	0---127 128---191 192---255	Position 0° ---->360° (FINE in CH9) CW SlowRotation-----> FastRotation CCW FastRotation----->SlowRotation

GOBO1 indexRotation FINE	12		0---255	GOBO1 index Rotation FINE
FORST	13	10	0---127 128--255	EXCLUDED INSERTED
PRISM2	14	11	0---127 128--255	EXCLUDED INSERTED
PRISM2 Rotation	15	12	0---127 128---190 191---194 195---255	Position 0° ---->360° CW FastRotation-----> SlowRotation STOP CCW Slow Rotation----->Fast Rotation
FOCUS	16	13	0---255	
ZOOM	17	14	0---255	
PAN(X)	18	15	0---255	
PAN(X) FINE	19	16	0---255	
TILTE(Y)	20	17	0---255	
TILTE(Y) FINE	21	18	0---255	
P/T SPEED	22	19	0---128 129---170 171---211 212---255	Fastest----->Slowest Slow Speed (1/3 MaxSpeed) Medium Speed (1/2 MaxSpeed) Fast Speed (Fastest Speed)
Lamp Control	23	20	0---32 33---64 65---96 97---128 129---160 161---193 194---225 226---255	Undefined Undefined Undefined Undefined Undefined Undefined Undefined Undefined
Control	24	21	0---127 128---255	Undefined Reset ALL(>4s)